

NEW DSTV HD DECODER SETTINGS



Please note these instructions do not work on PVR decoders.

Press the **BLUE DSTV** button on your remote.

Go to **Settings**

Go to **Satellite Settings > Additional Settings** – press **OK**.

Make sure the following codes are all the same on **Network 2**:

Enable Network: Yes

Use NIT: Yes

Frequency: 12682

Modulation: DVB-S

Symbol Rate: 27500

FEC: 3/4

Polarization: Horizontal

Go to **Scan this** – press **OK**.

Once scanning is complete press the **BLUE DSTV** button.

Go to **Planner**

TV Guide > All Channels – press **OK**.

SCROLL DOWN TO FIND **CHRIST MEDIA TELEVISION** – press **OK**.

NB: ADD THE CHANNEL TO YOUR FAVOURATES TO EASILY TUNE-IN. BE CONNECTED.